18/03/2021	SAF-ID-6000 4200132 Nome - Agush Jain Engineering Chemistry Tutorial - 2 - Water
0	A 50 ml of water sample contains 500 ppm of dissolved oxygen. The water sample is diluted to 100 ml. After 5 days of incubation the DO value of water sample reduces to 400 ppm. Calculate BOD of water sample.
Ans	(niven: Water sample before dilution = 50 ml. Water sample after dilution = 100 ml. DOb = 500 ppm DOi = 400 ppm
6	BOD = [DOB - DOi] × Dilution factor. [DOB - DOi] × ml. of sample after dilution ml. of sample before dilution = [500 - 400] × 100 50
	= 100 × 100 500 = 200 PPM
2	FOR EDUCATIONAL USE

	Page 2
	DATE
2.>	ond of wester was refluxed with 20 ml of k2(r207) and after refluxing the excess unreacted dichromate required 26.2 ml of 0.1 N FAS solution. A blank of 10 ml of distilled water on refluxing with 20 ml of K2(r207 solution required 36 ml of 0.1 N FAS solution. Calculate the COD of waste water sample.
Salution:	alven:
COTOTION	VB = 36 m1
	Vt = 26.2m1
	N = 0.1 normal
	Ve = 10 m1
	:. COD = (VB-V+) × N × 8000 Ve
	= (36 - 26.2) ×0·1 × 8000
	= 784 PPM
	: COD of waster water sample is 784 ppm.
2	FOR EDUCATIONAL USE